

<Operationmanual\_Advanced\_Gripping\_BuR\_AS\_V2(EN).docx>

topic:

<FB Advanced Gripping>

version:

<2.0>

### History

Author	Reason for change/changes made	Release	Date
Nock	Creation	1.0	03.04.2019
Nock	Completion header and extensioning DataTransfer	1.1	04.09.2019
Nock	Displaying parameter change with output bit Bugfix: holding pressure current at mode 63, 73, 85, 95 Automatic reset of the direction flags	1.21	13.03.2020
Nock	Selection of Homing-DeviceMode Compatibility with GEP2000IL-03-B Optimization of drive command routines Optimization of the MotorON routine Bugfix: "DataTransferError"	2.0	01.08.2021

### Inhalt


1	Foreword.....	4
2	Integrating the library.....	4
3	CYCLIC .....	5
4	Variables .....	6
5	Using the function block.....	6
6	Functions of the function block.....	7
6.1	Resetting the step sequence „Inp_cmd_b_StepReset“ (BOOL) .....	7
6.2	Switching on motor „Inp_cmd_b_MotorON“ (BOOL) .....	7
6.3	Switching off motor „Inp_cmd_b_MotorOFF“ (BOOL).....	8
6.4	Referencing the gripper „Inp_cmd_b_StartHoming“ (BOOL).....	8
6.5	Transferring data with handshake „Inp_cmd_b_DataTransfer“ (BOOL) .....	8
6.6	Saving workpiece recipes „Inp_cmd_b_WritePDU“ (BOOL).....	8
6.7	Resetting the direction flags „Inp_cmd_b_ResetDirectionFlag“ (BOOL).....	8
6.8	Drive to BasePosition „Inp_cmd_b_MoveToBase“ (BOOL) .....	8
6.9	Drive to WorkPosition „Inp_cmd_b_MoveToWork“ (BOOL) .....	9
6.10	Jog in direction WorkPosition „Inp_cmd_b_JogToWork“ (BOOL) .....	9
6.11	Jog in direction BasePosition „Inp_cmd_b_JogToBase“ (BOOL).....	9
6.12	Limiting of the motion time „Inp_t_MotionTimeout“ (TIME) and „Out_b_MotionError“ (BOOL)..	9
6.13	Switchover to use of a GEP2000IL-03-B "Inp_b_GEP2000_03" (BOOL) .....	9
6.14	Setting homing mode "Inp_i8_DeviceModeHoming" (BYTE) .....	9
6.15	Data transfer is required „Out_b_DataTransferRequired“ (BOOL) .....	9
6.16	Error in the DataTransfer „Out_b_DataTransferError“ (BOOL).....	9
6.17	Function block is busy „Out_b_StepBusy“ (BOOL) .....	9
6.18	Ready for commands „Out_b_StepDone“ (BOOL) .....	10
6.19	Bit 0 of the StatusWord „Out_b_HomingPositionOK“ (BOOL) .....	10
6.20	Bit 1 of the StatusWord „Out_b_MotorON“ (BOOL) .....	10
6.21	Bit 2 of the StatusWord „Out_b_InMotion“ (BOOL).....	10
6.22	Bit 3 of the StatusWord „Out_b_MovementComplete“ (BOOL) .....	10
6.23	Bit 4 of the StatusWord „Out_b_JogBaseActive“ (BOOL).....	10
6.24	Bit 5 of the StatusWord „Out_b_JogWorkActive“ (BOOL).....	10
6.25	Bit 6 of the StatusWord „Out_b_GripperPLCActve“ (BOOL) .....	10
6.26	Bit 7 of the StatusWord „Out_b_ControllerError“ (BOOL) .....	10
6.27	Bit 8 of the StatusWord „Out_b_BasePosition“ (BOOL) .....	10
6.28	Bit 9 of the StatusWord „Out_b_TeachPosition“ (BOOL) .....	10
6.29	Bit 10 of the StatusWord „Out_b_WorkPosition“ (BOOL).....	10
6.30	Bit 11 of the StatusWord „Out_b_UndefinedPosition“ (BOOL).....	10
6.31	Bit 12 of the StatusWord „Out_b_DataTransferOK“ (BOOL) .....	11

6.32	Bit 13 of the StatusWord „Out_b_ControlWord_100“ (BOOL).....	11
6.33	Bit 14 of the StatusWord „Out_b_ControlWord_200“ (BOOL).....	11
6.34	Bit 15 of the StatusWord „Out_b_Error“ (BOOL) and „Out_i16_Diagnose“ (WORD) .....	11
6.35	Actual position "Out_i16_ActualPosition" (WORD) .....	11


## 1 Foreword

To use the function block, a correct hardware configuration must first be created. In this example, a B&R X20CP1301 controller with a B&R X20DS438A IO Link master is used. After the hardware settings have been made, the function block can be implemented. To do this, follow the steps below.


## 2 Integrating the library



To include a library click on the "File" tab and select "Import ...". A window will appear where you can search and open the library. Please select the zip file "ZG\_Advanced\_Gripping\_AS\_V2.0".




After opening, the required global data types, standard libraries, pre-declared variables and the function block with the variable declaration are now available.



### 3 CYCLIC

Open the main program in the "Logical View" in the PLC program and drag the function block "ZG\_FB\_Advanced\_Gripping\_V2" onto the programming surface.



An instance of the function block named "Gripper\_1" has already been created for the block. Write this via the function block. If you are using several grippers, you will need a correspondingly large number of function blocks and will have to create additional instances for them under the "Variables.var".


Gripper_1		1
ZG_FB_Advanced_Gripping_V2		
Inp_st_GripperData_IN	Out_st_GripperData_OUT	
Inp_cmd_b_StepReset	Out_b_DataTransferRequired	
Inp_cmd_b_MotorON	Out_b_DataTransferError	
Inp_cmd_b_MotorOFF	Out_b_MotionError	
Inp_cmd_b_StartHoming	Out_b_StepBusy	
Inp_cmd_b_DataTransfer	Out_b_StepDone	
Inp_cmd_b_WritePDU	Out_b_HomingPositionOK	
Inp_cmd_b_ResetDirectionFlag	Out_b_MotorON	
Inp_cmd_b_MoveToBase	Out_b_InMotion	
Inp_cmd_b_MoveToWork	Out_b_MovementComplete	
Inp_cmd_b_JogToWork	Out_b_JogBaseActive	
Inp_cmd_b_JogToBase	Out_b_JogWorkActive	
Inp_t_MotionTimeout	Out_b_GripperPLCActive	
Inp_b_GEP2000IL_03	Out_b_ControllerError	
Inp_i8_DeviceModeHoming	Out_b_BasePosition	
Inp_i8_DeviceMode	Out_b_TeachPosition	
Inp_i8_WorkpieceNo	Out_b_WorkPosition	
Inp_i8_PositionTolerance	Out_b_UndefinedPosition	
Inp_i8_GripForce	Out_b_DataTransferOK	
Inp_i8_DriveVelocity	Out_b_ControlWord_100	
Inp_i16_BasePosition	Out_b_ControlWord_200	
Inp_i16_ShiftPosition	Out_b_Error	
Inp_i16_TeachPosition	Out_i16_Diagnose	
Inp_i16_WorkPosition	Out_i16_ActualPosition	

Nomenclature:

Prefix	Meaning
Inp	Input variable
Out	Output variable
cmd	Command input
b	Binary signal (BOOL)
i8	Variable in byte size (BYTE)
i16	Variable in word size (WORD)
st	Data structure (STRUCT)
t	Time (TIME)
g	Global variable


## 4 Variables

Variables for the input and output data of the gripper with the correct data type are already created in the variable table.



Name	Typ	& Referenz	Konstante	Retain	Duplizierbar	Wert	Beschreibung [1]
g_st_Gripper1_IN	ST_Advanced_IN_z	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>		
g_st_Gripper1_OUT	ST_Advanced_OUT_z	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>		
Gripper_1	ZG_FB_Advanced_Gripping_V2	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input checked="" type="checkbox"/>		

To assign physical addresses to these variables, please switch to the "Physical View" and select your used IO Link Master. Go to the "I/O Assignment" with a right click. Provided that the ports of the IO Link master have been configured correctly, the "InputData01" and "OutputData01" appear in the "I/O Assignment". The length of the data type must be set correctly. Select the corresponding variables in the "Process variables" column.



Kanalname	Prozessvariable	Datentyp	Taskklasse	Invertiert	Simulation	Quelldatei	Beschreibung [1]
ModuleOk		BOOL					Modul Status (1 = Modul gesteckt)
StateData		BOOL					Daten stammen nicht aus aktuellem Zyklus
SerialNumber		UDINT					Seriennummer
ModuleID		UINT					Modulkennung
HardwareVariant		UINT					Hardware Variante
FirmwareVersion		UINT					Firmware Version
ChannelStatus01		USINT					Betriebszustand IO-Link Schnittstelle 1
InputData01	::Program1:g_st_Gripper1_IN	OCTET[6]	Automatisch	<input type="checkbox"/>	<input type="checkbox"/>	\X20CP1301\IoMap...	Eingangsprozessdaten, Kanal 1
OutputData01	::Program1:g_st_Gripper1_OUT	OCTET[16]	Automatisch	<input type="checkbox"/>	<input type="checkbox"/>	\X20CP1301\IoMap...	Ausgangsprozessdaten, Kanal 1

## 5 Using the function block


To enable the function block to access the address ranges of the IO-Link data, the variables "Inp\_st\_GripperData\_IN" and "Out\_st\_GripperData\_OUT" must be linked to the variables created in point 4. The gripper can be parameterized by writing to the input variables on the module.

To move the gripper, the position and travel data must be transferred. The values listed in the following table can be used as standard values. Other values may prove to be more suitable. Please refer to the installation and operating instructions. You can enter these parameters as constants on the module, as in this example, or you can use variables of the appropriate length, so that the circuitry is flexible. When not connected, the variables are pre-initialized with the default values.

Variable	Value
Inp_t_MotionTimeout	T#15s
Inp_i8_DeviceMode	60
Inp_i8_WorkpieceNo	0
Inp_i8_PositionTolerance	50
Inp_i8_GripForce	4
Inp_i8_DriveVelocity	4
Inp_i16_BasePosition	75
Inp_i16_ShiftPosition	800
Inp_i16_TeachPositon	1000
Inp_i16_WorkPosition	1200

The "Inp\_i8\_DeviceMode" variable corresponds to the travel profile of the gripper. These travel profiles can be found in the installation and operating instructions for the gripper. In this example, the DeviceMode 60 was selected, which corresponds to the travel profile "Force profile external gripping".

The finished module should now correspond to the above figure.



Finally, compile the settings and transfer them to the target system.

## 6 Functions of the function block

Depending on the input wiring of the function block, the corresponding functions are executed. Further information can also be found in the comments in the block header.

### 6.1 Resetting the step sequence „Inp\_cmd\_b\_StepReset“ (BOOL)

The input variable "Inp\_cmd\_b\_StepReset" resets the step chain within this block. This happens regardless of which step the block is currently in. If the block issues the error "Out\_b\_DataTransferError" or "Out\_b\_MotionError", it can only be acknowledged by this input.

### 6.2 Switching on motor „Inp\_cmd\_b\_MotorON“ (BOOL)

The gripper can only move when the motor is switched on. The gripper represents its states in the "Status-Word". If the gripper is switched off, the "Out\_b\_MotorON" signal is "FALSE". If the signal edge is positive,

the motor is switched on and the "Out\_b\_MotorON" signal is set to "TRUE". The function block converts this signal into "DeviceMode" 3 and sends it to the gripper. In order for the gripper to use this "DeviceMode", a data transmission with handshake must be carried out. After successful transfer of the data, the "b\_MotorON" bit changes from "FALSE" to "TRUE". The motor is now switched on. The function block does this automatically.

### 6.3 Switching off motor „Inp\_cmd\_b\_MotorOFF“ (BOOL)

To switch off the gripper motor, a positive signal edge must be set at the "Inp\_cmd\_b\_MotorOFF" input. The "DeviceMode" is automatically set to the value 5 and a data transfer is performed. The motor can be switched off at any time (except during a reference run) and is independent of which command the gripper has previously received.

### 6.4 Referencing the gripper „Inp\_cmd\_b\_StartHoming“ (BOOL)

The gripper must be referenced so that it can always output the correct position. The "Out\_b\_HomingPositionOK" signal indicates the current status of the referencing. If this signal is set to "FALSE", the gripper does not know in which position the gripper jaws are and process-safe operation would therefore not be guaranteed. The gripper can be referenced again with the "Inp\_cmd\_b\_StartHoming" signal. There are different referencing modes that can be set with the "Inp\_i8\_DeviceModeHoming" input. With a positive signal edge, the gripper starts a new homing run with the set referencing mode. A reference run must not take place in the gripped state. Make sure in advance that the gripper is free to move.

### 6.5 Transferring data with handshake „Inp\_cmd\_b\_DataTransfer“ (BOOL)

After each change of a process parameter (except "ControlWord") or at a cold start of the gripper, the parameters must be taken over with a data transfer. If the "Out\_b\_DataTransferRequired" output variable is "TRUE", the gripper is not yet operating with the currently set parameters. In this case, the process parameters must be transferred with a positive signal edge at the "Inp\_cmd\_b\_DataTransfer" input. The variable "Out\_b\_DataTransferRequired" then changes to "FALSE". Thereby the "ControlWord" is set to value 1 and waits for bit 12 of the "Status-Word". Bit 12 becomes "TRUE" as soon as the data transfer is completed. Then the "ControlWord" is set to 0 again and waited until bit 12 becomes "FALSE". This procedure is a handshake and should be used for error-free data transfer.

### 6.6 Saving workpiece recipes „Inp\_cmd\_b\_WritePDU“ (BOOL)

With a positive signal edge, the currently set process parameters at the function block input are stored in the currently set "WorkpieceNo". The "ControlWord" is set to value 2 and bit 12 of the "StatusWord" is waited for. This procedure can take up to 30 seconds. The parameters are stored in the internal recipe locations and can be reloaded by specifying the "WorkpieceNo". Up to 32 recipes can be stored in the gripper.

### 6.7 Resetting the direction flags „Inp\_cmd\_b\_ResetDirectionFlag“ (BOOL)

If a gripper is moved in the direction of "WorkPosition", for example, bit 14 of the "Status word" is set in the gripper. This signal remains until a movement in the other direction or a cold start of the gripper. If a gripper is to be moved several times in succession in the same direction, e.g. by changing positions, then this bit must first be reset. This can be done by a positive signal edge at the input "Inp\_cmd\_b\_ResetDirectionFlag". Thereby the "ControlWord" is set to the value 4 and waits until bit 13 and bit 14 of the "StatusWord" change to "FALSE". After this, a new movement in the same direction can take place. From function block version V1.21 onwards, this procedure is carried out automatically before the gripper is moved, if necessary.

### 6.8 Drive to BasePosition „Inp\_cmd\_b\_MoveToBase“ (BOOL)

With a positive signal edge, the gripper jaws move with the set travel profile in the direction of the set "BasePosition". The "ControlWord" is set to the value 256.



### 6.9 Drive to WorkPosition „Inp\_cmd\_b\_MoveToWork“ (BOOL)

With a positive signal edge, the gripper jaws move with the set travel profile in the direction of the set "WorkPosition". The "ControlWord" is set to the value 512.

### 6.10 Jog in direction WorkPosition „Inp\_cmd\_b\_JogToWork“ (BOOL)

The gripper moves in inching mode. No software limit switches are active in this mode. When this input is set to "TRUE", the "DeviceMode" is automatically set to the value 11, a handshake is performed and the corresponding bit of the "ControlWord" is set. The gripper jaws move at low speed in the direction of the "WorkPosition". When the input is set to "FALSE", the gripper stops again.

### 6.11 Jog in direction BasePosition „Inp\_cmd\_b\_JogToBase“ (BOOL)

The gripper moves in inching mode. No software limit switches are active in this mode. When this input is set to "TRUE", the "DeviceMode" is automatically set to the value 11, a handshake is performed and the corresponding bit of the "ControlWord" is set. The gripper jaws move at low speed in the direction of the "BasePosition". When the input is set to "FALSE", the gripper stops again.

### 6.12 Limiting of the motion time „Inp\_t\_MotionTimeout“ (TIME) and „Out\_b\_MotionError“ (BOOL)

The "Inp\_t\_MotionTimeout" time can be used to define the maximum time the gripper may take to move until it reaches its target position. This depends on the parameterization of the gripper and must be adapted project-specifically. If the gripper does not reach its target position within the set time, the "MotionError" error is activated. The "Out\_b\_MotionError" output is set to "TRUE".

### 6.13 Switchover to use of a GEP2000IL-03-B "Inp\_b\_GEP2000\_03" (BOOL)

In addition to the GEH6000IL, this function block is also compatible with the GEP2000IL-03 gripper series. Setting the input to "TRUE" signals to the function block that it is operated with a GEP2000IL-03-B. The functions that a GEP2000IL-03-B does not have compared to a GEH6000IL are thus deactivated.

### 6.14 Setting homing mode "Inp\_i8\_DeviceModeHoming" (BYTE)

The desired referencing mode (e.g. "14" for DeviceMode 14) can be set at this input. The modes can be taken from the installation and operating instructions. When not connected, DeviceMode 10 is set as default. It is not allowed to connect the input with the value "0". Homing is started with the "Inp\_b\_cmd\_StartHoming" input (see 6.4).

### 6.15 Data transfer is required „Out\_b\_DataTransferRequired“ (BOOL)

The variable "Out\_b\_DataTransferRequired" is automatically activated if at least one process parameter was changed at the inputs. As long as this variable is active, the gripper has not yet transferred the changed values. For data transfer, a positive signal edge must be set at the "Inp\_cmd\_b\_DataTransfer" input variable. The "Out\_b\_DataTransferRequired" variable then changes to "FALSE" and the gripper uses the currently set parameters.

### 6.16 Error in the DataTransfer „Out\_b\_DataTransferError“ (BOOL)

The "Out\_b\_DataTransferError" output is set to "TRUE" if the data transfer could not be carried out successfully and the feedback of the gripper was not sent within one second. This can occur, among other things, if the set process parameters are not plausible. The error code can be taken from the variable "Out\_i16\_Diagnose". The error codes are described in more detail in the installation and operating instructions. This error can be acknowledged by setting the "Inp\_cmd\_b\_StepReset" input.

### 6.17 Function block is busy „Out\_b\_StepBusy“ (BOOL)

If the block is processing a command and is in a step, this output is active and signals that it is blocked for further commands.

#### 6.18 Ready for commands „Out\_b\_StepDone“ (BOOL)

If the block is in the initial step and ready for commands, this output is "TRUE". Querying this bit before a command for programming step chains is recommended.

#### 6.19 Bit 0 of the StatusWord „Out\_b\_HomingPositionOK“ (BOOL)

The gripper has an internal distance measuring system which does not have to be referenced under normal circumstances. As long as the gripper has a valid referencing, this signal is active. As soon as this signal is set to "FALSE", the gripper must be referenced again (see 6.4).

#### 6.20 Bit 1 of the StatusWord „Out\_b\_MotorON“ (BOOL)

As long as this signal is "FALSE", the gripper cannot be moved. The motor of the gripper must first be switched on (s 6.2).

#### 6.21 Bit 2 of the StatusWord „Out\_b\_InMotion“ (BOOL)

This signal is active as long as the gripper jaws are moving.

#### 6.22 Bit 3 of the StatusWord „Out\_b\_MovementComplete“ (BOOL)

This signal indicates that a movement has been completed and the gripper is at a standstill.

#### 6.23 Bit 4 of the StatusWord „Out\_b\_JogBaseActive“ (BOOL)

This signal is active as long as the gripper is controlled in jog mode and moved in the direction of the "Base position".

#### 6.24 Bit 5 of the StatusWord „Out\_b\_JogWorkActive“ (BOOL)

This signal is active as long as the gripper is controlled in jog mode and moved in the direction of the "WorkPosition".

#### 6.25 Bit 6 of the StatusWord „Out\_b\_GripperPLCActive“ (BOOL)

This signal indicates the operational readiness of the control in the gripper. In the event of a cold start or restart after a power failure, the gripper can only receive data again when this signal is "TRUE".

#### 6.26 Bit 7 of the StatusWord „Out\_b\_ControllerError“ (BOOL)

Error in the internal controller.

#### 6.27 Bit 8 of the StatusWord „Out\_b\_BasePosition“ (BOOL)

As soon as the gripper has reached its set "BasePosition" and is at standstill, this signal is activated. The size of the range is defined by the "PositionTolerance".

#### 6.28 Bit 9 of the StatusWord „Out\_b\_TeachPosition“ (BOOL)

As soon as the gripper has reached its set "TeachPosition" and is at standstill, this signal is activated. The size of the range is defined by the "PositionTolerance".

#### 6.29 Bit 10 of the StatusWord „Out\_b\_WorkPosition“ (BOOL)

As soon as the gripper has reached its set "WorkPosition" and is at standstill, this signal is activated. The size of the range is defined by the "PositionTolerance".

#### 6.30 Bit 11 of the StatusWord „Out\_b\_UndefinedPosition“ (BOOL)

If the gripper is stationary and is neither at "BasePosition" nor at "TeachPosition" or "WorkPosition", this signal is "TRUE".

#### 6.31 Bit 12 of the StatusWord „Out\_b\_DataTransferOK“ (BOOL)

With this bit the gripper gives the feedback that a data transmission has been successfully executed. Therefore it is used in a handshake procedure.

#### 6.32 Bit 13 of the StatusWord „Out\_b\_ControlWord\_100“ (BOOL)

This direction flag becomes active when the gripper has received a "MoveToBase" command. The gripper cannot execute another "MoveToBase" command in this state. The flag is set to "FALSE" again when the gripper receives a "MoveToWork" command or a reset is performed manually via "Inp\_cmd\_b\_ResetDirectionFlag" (see 6.7).

#### 6.33 Bit 14 of the StatusWord „Out\_b\_ControlWord\_200“ (BOOL)

This direction flag becomes active when the gripper has received a "MoveToWork" command. The gripper cannot execute another "MoveToWork" command in this state. The flag is set to "FALSE" again when the gripper receives a "MoveToBase" command or a reset is performed manually via "Inp\_cmd\_b\_ResetDirectionFlag" (see 6.7).

#### 6.34 Bit 15 of the StatusWord „Out\_b\_Error“ (BOOL) and „Out\_i16\_Diagnose“ (WORD)

If the diagnostic value of the gripper is not 0, this bit is set. The error code is output in the data word "Out\_i16\_Diagnose". The descriptions of the error codes can be taken from the assembly and operating instructions.

#### 6.35 Actual position "Out\_i16\_ActualPosition" (WORD)

In this data word the actual position of the gripper jaws is output in 0.01mm.