## 2-JAW PARALLEL GRIPPERS **SERIES GPP5000IL**

## PRODUCT ADVANTAGES





## "The hybrid"


- ► Pneumatic drive combined with IO-Link technology
- ▶ Up to 50% reduction in cycle times and up to 90% less compressed air usage
- ► Connection over just one pneumatic line and IO-Link
- Integrated valve technology, sensor technology, status display, pressure monitoring and temperature monitoring
- ▶ Part detection down to +/- 0.05 mm for a tolerance range that can be taught for any value
- > 32 workpieces data sets can be programmed
- Protected from corrosion and sealed in accordance with IP64
- ▶ Up to 30 million cycles without maintenance

## SERIES CHARACTERISTICS

Installation size	Version					
GPP50XXIL	N	NC	NO	S	SC	SO
<b>♦ IO</b> -Link	•	•	•	•	•	•
Spring closing C		•			•	
Spring opening O			•			•
F) High-strength S				•	•	•
30 million maintenance-free cycles (max.)	•	•	•	•	•	•
Integrated sensing	•	•	•	•	•	•
Integrated valve technology	•	•	•	•	•	•
Protected against corrosion	•	•	•	•	•	•
Purged air	•	•	•	•	•	•
IP 64 IP64	•	•	•	•	•	•



### **BENEFITS IN DETAIL**



#### 1 Wedge hook mechanism

- Supports to absorb high forces and moments
- Synchronized gripper jaw movement

#### (2) Gripper jaw

- Gripper fingers mounted using removable centering sleeves
- Lubricated for life via incorporated lubrication slots

#### 3 Steel Linear Guide

- Steel in steel guide
- Enables use of extremely long gripper fingers

#### 4 Dual lip seal

- IP64
- Prevents grease from being squeezed out, increasing service life

### 5 Integrated gripping force safety device

- Spring built into cylinder chamber as an energy store

### 6 Mounting and positioning

- Alternatively, on several sides for customized mounting

#### 7 Position sensing

- integrated Hallsensor

#### 8 Integrated valve technology

- Activation of the gripper by means of a compressed air supply

#### 9 Integrated control module

- Single-cable solution via IO-Link
- Pressure, temperature, position and other parameters are readable

## **TECHNICAL DATA**

	Stroke per jaw	Gripping force	Weight	IP class
Installation size	[mm]	[N]	[kg]	
GPP5006IL	3 - 6	330 - 1080	0,45 - 0,53	IP64
GPP5008IL	4 - 8	520 - 1670	0,75 - 0,87	IP64
GPP5010IL	5 - 10	885 - 2890	1,23 - 1,45	IP64
GPP5013IL	6 - 13	1410 - 4400	2,5 - 2,9	IP64
GPP5016IL	8 - 16	2090 - 6600	4,4 - 5,1	IP64
GPP5025IL	14 - 25	3280 - 9130	8,5 - 10,4	IP64

### ► FURTHER INFORMATION IS AVAILABLE ONLINE




All information just a click away at: <a href="www.zimmer-group.com">www.zimmer-group.com</a>. Find data, illustrations, 3D models and operating instructions for your installation size using the order number for your desired product. Quick, clear and always up-to-date.

# 2-JAW PARALLEL GRIPPERS **INSTALLATION SIZE GPP5013IL**

## ► PRODUCT SPECIFICATIONS



#### Gripping force diagram



#### Forces and moments

Displays static forces and moments that can also have an effect, besides the gripping force.





Mr [Nm]	110
Mx [Nm]	150
My [Nm]	130
Fa [N]	3300

## **► TECHNICAL DATA**

	► Technical data					
Order no.	GPP5013N-IL-10-A	GPP5013NC-IL-10-A	GPP5013NO-IL-10-A	GPP5013S-IL-10-A	GPP5013SC-IL-10-A	GPP5013SO-IL-10-A
Control	<b>② IO</b> -Link	<b>O</b> IO-Link				
Stroke per jaw [mm]	13	13	13	6	6	6
Gripping force in closing [N]	1410	1920		3100	4220	
Gripping force in opening [N]	1490		1860	3280		4400
Gripping force secured by spring min. [N]		510	510		1120	1120
Cycle count max. [cycle/min]	310	220	220	310	220	220
Dead weight of mounted gripper finger max. [kg]	2.4	2.4	2.4	2.4	2.4	2.4
Length of the gripper fingers max. [mm]	200	185	185	185	170	170
Repetition accuracy +/- [mm]	0.01	0.01	0.01	0.01	0.01	0.01
Operating pressure [bar]	3 8	4 7	4 7	3 8	4 7	4 7
Nominal operating pressure [bar]	6	6	6	6	6	6
Operating temperature [°C]	+5 +50	+5 +50	+5 +50	+5 +50	+5 +50	+5 +50
Air volume per cycle [cm³]	88	171	171	88	171	171
Integrated valve technology	Yes	Yes	Yes	Yes	Yes	Yes
Integrated position sensing	Yes	Yes	Yes	Yes	Yes	Yes
Voltage [V]	24	24	24	24	24	24
Current consumption max. [A]	0.12	0.12	0.12	0.12	0.12	0.12
Approvals	CE / UKCA / LABS / REACH / RoHS					
Protection to IEC 60529	IP64	IP64	IP64	IP64	IP64	IP64
Weight [kg]	2.5	2.9	2.8	2.5	3	2.9

## **► TECHNICAL DRAWINGS**






- ① Gripper attachment
- 2 Energy supply
- 3 Fixing for gripper finger
- 19 Air purge connection option
- 23 Ventilation (R+S: In dirty environments, replace filters with actual exhaust hoses and move the exhaust air outlet to a clean environment)
- 35 Attachment option for customer-specific fittings
- 46 Energy supply IO-Link (M12, 5-pole)
- 49 Ground
- 6) Status display



# 2-JAW PARALLEL GRIPPERS **INSTALLATION SIZE GPP5013IL**

## **ACCESORIES**



## ► INCLUDED IN DELIVERY



4 [piece] Centering Disc

018187



2 [piece] Centering Disc



019280

CFILT00011

## ► RECOMMENDED ACCESSORIES



## **GRIPPING COMPONENTS**



UB5013AL Universal jaw aluminium



UB5013ST Universal jaw steel



EB5013AL Aluminum adjustment jaw



EB5013ST Steel adjustment jaw



WB5013L Changeable jaw, loosepart-set



WB5013F Changeable jaw, fix-part



## **ENERGY SUPPLY**



GV1-8X8 Straight Fittings - Quick Connect Style



## **CONNECTIONS / OTHER**



KAG500IL Plug-in connector straight 5 m - plug, socket M12




SCM-C-00-00-A Smart Communication Module

## 2-JAW PARALLEL GRIPPERS SERIES GPP5000IL FUNCTIONAL DESCRIPTION




## **GRIPPING COMPONENTS**



#### Universal jaws - UB5000

Can be used immediately or for individual reprocessing


The gripper blanks are available in aluminum (AL) and steel (ST) versions and are installed directly on the gripper using the screws in the scope of delivery. The fits for the centering sleeves are already in place for this purpose. One universal jaw is required for each gripper jaw.



## Adjustment jaws - EB5000

For tool-free adaptation of the gripper range

By manually activating the locking mechanism, which is pre-tensioned by a spring, the adjustment jaw can be moved within a grid of detent notches that has a number scale. Depending on the forces and torques that apply, the adjustment jaws are available in aluminum (AL) and steel (ST) versions. One adjustment jaw is required for each gripper jaw.



#### Interchangeable jaws - WB5000

Enable fast change of individual gripper fingers

For each gripper jaw, a fixed part and at least one loose part set is needed, depending on the number of gripper fingers to be changed. Manual locking via the Torx wrench included in the scope of delivery of the fixed part can take place from two sides.




## THE GRIPPING COMPONENTS CAN BE COMBINED!

The gripper components listed above can be combined with each other and are compatible with the various series of the 5000 gripper family.








### **Pneumatic threaded connections**

Available in straight and angled design. Can be chosen freely depending on the space conditions or installation situation.




### Pressure safety valve - DSV

The throttle check valve integrated into the supply air line retains the system pressure in case of EMERGENCY STOP. To ensure the function, the valve must be installed as close to the gripper's air connection as possible. Control voltage and actuator voltage must be maintained for this purpose.

# 2-JAW PARALLEL GRIPPERS **SERIES GPP5000IL FUNCTIONAL DESCRIPTION**



## CONNECTIONS / OTHER




## **Centering sleeves**

For defined position measurement of the gripper fingers


The centering sleeves are inserted into the fits of the gripper jaws to define the position of the gripper fingers. The centering sleeves are comparable to a pin connection.

# **SECURED CONFIGURATION EXAMPLES** GPP5000IL / GPD5000IL SERIES


## ► GPP5000IL / GPD5000IL (IO-LINK) WIRING TO CONTROL CABINET (BECKHOFF)



## ► GPP5000IL / GPD5000IL (IO-LINK) WIRING TO CONTROL CABINET (SIEMENS)



## ► GPP5000IL / GPD5000IL (IO-LINK) WIRING TO IO-LINK MASTER IP67 (BECKHOFF)



## ► GPP5000IL / GPD5000IL (IO-LINK) WIRING TO IO-LINK MASTER IP67 (SIEMENS)

